
Parts

- **A.** 1 x Gazebo Frame
- **B.** 1 x Half Wall Cross Bar (Optional)
- **c.** 1 x Print





Technical Data - Event Gazebo







Assembly

Carefully draw the frame outwards to partially expand. Place the canopy print over the frame, lining up the centre of the canopy with the middle point of the frame. Then continue to extend the frame outwards.



2

3



Place the corners of the canopy over each corner of the frame. Attach the canopy to the frame using the velcro located in all of the corners.





To secure the frame, push the upper frame sections on all four corners into the holes located at the top of the frame ensuring it clicks into place. This may require some force.







Securing the base of each leg in position with your foot, depress the red button and adjust the height of the frame. Release the button and slide the frame over the holes to secure the desired height.



