



## Parts

- A.** 1 x Water Base
- B.** 1 x Pole Arm
- C.** 1 x Pole
- D.** 1 x Base Adaptor



## Technical Data - Portable Mini Event Flagpole



**Time Required**  
< 15 mins

**People Required**  
1 person

**Tools Required**  
None

**HARRISON**  
FLAGPOLES | EDS | CREATIVE

## Assembly

Remove the top cap by turning anti clockwise and remove the arm from inside of the pole.

1



Extend the pole by turning the adjuster anti clockwise and pulling apart, extend the pole to the desired height or maximum of 3m.

2



Insert the extended telescopic pole into the base of the flag sleeve on the longest side of the flag until visible at the top of the sleeve.

3



Unscrew the top cap ensuring sufficient space for the arm to be inserted. Insert the arm into the top sleeve as shown. Insert the thinner end through the top cap and hand tighten.

4



Insert the thinner end through the top cap and hand tighten. As shown in the dimensions sheet, it is recommended that the arm should protrude 160mm from the pole as shown.

5



Remove the plug from the plastic base and fill with water or sand to add weight then replace.

6



Insert the pole into the base adaptor and tighten the retaining ring. Hold the pole central while tightening to ensure pole is straight.

7

